




## ADX-500 Ultra Low Noise Active DI Box



Front view




- ① INPUT : 1/4" jack unbalanced
- ② INPUT : XLR F 3 pin socket unbalanced
- ③ LINK / MONITOR : 1/4" jack unbalanced
- ④ PAD : 0 dB , 20 db

The SOUNDSATION ADX-500 ACTIVE BOX is an electronic device that converts an unbalanced audio signal into a balanced signal . You can connect unbalanced input devices like an electric bass, a guitar or a keyboard. The balanced line is less sensitive to electromagnetic interferences and has a better S/N ratio. In this way it is possible to achieve a good performance in case of long distances as well. For instance, it is possible to connect your instrument to a distant mixer maintaining a good quality signal. The ADX-500 is highly recommended for sound engineers and stage/studio performers .

### Specifications

Frequency response : 30Hz-20KHz  
 Maximum input level: 0 ±20dB  
 Noise level : ≤ 105 dBU  
 Phantom Power Requirement: 20~48V DC  
 Battery : 9V blockcell 6LR91  
 Dimension : 145X125X59mm  
 Weight : 700 g

Rear view



- ⑤ OUTPUT : XLR M 3 pin socket
- ⑥ Ground Lift Switch : activate/deactivate the ground
- ⑦ On/off Switch : power on/off the device
- ⑧ Battery case : hosts the 9V battery

Technical specifications and appearance subject to change without notice. The information contained herein is correct at the time of printing.



### WARNING

Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions.  
 Do not use this apparatus near water. Clean only with dry cloth.  
 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.  
 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.  
 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.  
 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.  
 Unplug this apparatus during lightning storms or when unused for long periods of time.  
 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.