

SOUNDSATION HM700 is a headset microphone optimal and versatile for use with many different applications. A conventional use is connection to a wireless set body pack or to a personal mini amplifier in tour guides apps. However it is possible any other use as microphone in connection with a mixer, an amplifier, PC and other electronic devices.

Features

- · Overhead wear style
- · cardioid directivity characteristic for eliminating unwanted noise
- light and comfortable wearing

Application: bodypacks, portable amps

Specifications:


• Transducer Principle: Back Electret Condenser

• Directivity Characteristic: Cardioid • Frequency Response: 50Hz-16kHz

 Sensitivity: -45dB±3dB (OdB=1V/Pa at 1kHz) • Output Impedance: 1000Ω±30% (at 1kHz)

• Max. Operating Voltage: 10V • Power Requirements: 1.5V

Frequency Response Graph:





HOW TO USE THE MICROPHONE

- Connect the mini jack terminal to the bodypack, mixer, amplifier or other device that is capable to supply 1,5V (check your equipment technical reference about this requirement) . In case your equipment cannot supply 1,5V power you can use an external power supply unit like SOUNDSATION PS168 (not included)
- Use the microphone in a proper way not exposing to water, moisture, electromagnetic field and extreme temperatures.
- Do not cover the head of the microphone by hand and do not place the microphone close to the speaker: a howling sound may be generated. To prevent this, first decrease the volume, then replace the microphone so that it is not pointed to the speaker and make sure there is a sufficient distance between the microphone and speaker.
- Due to the high sensitivity of the cartridge, do not drop it from high or apply strong shock to it.

WARRANTY AND SERVICE

All SOUNDSATION products feature a limited two-year warranty. This two-year warranty is specific to the date of purchase as shown on your purchase receipt.

The following cases/components are not covered from the above warranty :

- Any accessories supplied with the product
- Improper use
- Fault due to wear and tear
- Any modification of the product effected by the user or a third party

SOUNDSATION shall satisfy the warranty obligations by remedying any material or manufacturing faults free of charge at SOUNDSATION's discretion either by repair or by exchanging individual parts or the entire appliance. Any defective parts removed from a product during the course of a warranty claim shall become the property of SOUNDSATION

While under warranty period, defective products may be returned to your local SOUNDSATION dealer together with original proof of purchase. To avoid any damages in transit, please use the original packaging if available. Alternatively you can send the product to SOUNDSATION SERVICE CENTER - Via Enzo Ferrari , 10 - 62017 Porto Recanati - Italy . In order to send a product to service center you need an RMA number. Shipping charges have to be covered by the owner of the product.

For further information please visit www.soundsationmusic.com

PLEASE READ CAREFULLY - EU and EEA (Norway, Iceland and Liechtenstein) only



This symbol indicates that this product is not to be disposed of with your household waste, according to the WEEE Directive (2202/96/EC) and your national law.

This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (WEEE) .

Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources.

For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, approved WEEE scheme or your household waste disposal service.









This product is imported in EU by

FRENEXPORT SPA - Via Enzo Ferrari, 10 - 62017 Porto Recanati - Italy